

G102 | G203 LIGHTSYNC

Gaming Mouse

SETUP GUIDE




logitech ™


ПОДГОТОВКА К РАБОТЕ

Перед началом работы с устройством внимательно прочтите эти инструкции.

1 Подключите мышь к USB-порту компьютера.




2 Скачайте и установите ПО Logitech G HUB с веб-сайта logitechG.com/GHUB.



6 ПОЛНОСТЬЮ ПРОГРАММИРУЕМЫХ КНОПОК

По умолчанию эти кнопки запрограммированы следующим образом.

- 1 Щелчок основной кнопкой
- 2 Щелчок вспомогательной кнопкой
- 3 Нажатие колесика
- 4 Вперед
- 5 Назад
- 6 Циклическое изменение чувствительности



ПРОГРАММИРУЕМАЯ RGB-ПОДСВЕТКА С ПОДДЕРЖКОЙ ТЕХНОЛОГИИ LIGHTSYNC

У модели G102 / G203 LIGHTSYNC имеются 3 независимые зоны подсветки, которые легко настроить с помощью ПО Logitech G HUB. Вы можете применить для них любой цвет или анимационный эффект, например циклическую смену оттенков либо пульсацию.

Подсветку можно также синхронизировать с другими поддерживаемыми устройствами Logitech G, на которых установлено ПО Logitech G HUB.

Подробности см. на странице logitechG.com/GHUB





©2020 Logitech. Logitech, Logitech G, Logi and their respective logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

WEB-621-001682.002